The User Manual For MUT

Before using MUT, you must installed the Alarm Setting Tool with drivers.

Keep your main panel power OFF, connect it to PC via MicroUSB cable.

Turn ON your main panel, launch MUT.

MUT

## Select and open the correct COM port in MUT.

Remenber to choose the one with CH340 marked. After open the port, you will see the current firmware version as PROG:XXX. Make sure the firmware version you are going to update is greater than the main panel's.

PROG version: V2.0.0.2016.07.28-RS   LANG4 INFO: 04.160623(14), def

Pick the right firmware

Click "Upgrade Now" to update the firmware

Upgrade Tool V2.3

Ports: COM3:USB-SERIAL CH340   Open

PROG version: V2.0.0.2016.07.28-RS   LANG4 INFO: 04.160623(14), def

D:\Dinsafer\A003_V2.0.0.2016.07.28_BS.bin   Browse

Upgrade now

Please don't cut off the power when you are in the procedure of upgrading.

Now your main panel is up to date.